

Billion Dollar Art Gallery

with a Panasonic TV



1. Plug the BDAG memory stick into USB port. The gold connectors on the memory stick should be pointed to the right.
2. Press the **SD / USB** key. This is called the **Media Player** on some Panasonic remotes. The TV offers three choices of files. **Photos** is usually first. Press the **OK** key to choose photos
3. Press the **Play** key (the arrow key) to start the slide show the **direction** keys on your remote.

